Video Calibration and resolution Calibration

Sometimes it is necessary to calibrate the screen to get the corners of the screen visible and also to adjust the tv resolution to either 1080 or 720.
Do it as follows:

1. Click on the SYSTEM on the main bar.



2. Click on System at the bottom.



3. Click on the word Resolution to change it to suit your TV output, Normally 1080 or 720.



4. Next click the Video Calibration to bring the corners of the screen to the right place. Note you will need to calibrate for both 60HZ and 24HZ settings, if availiable.



5. Bring the top left corners in using the arrow keys, when done press Enter / OK to continue.



6. Next do the bottom right. Same way a previous step. When done press Enter / OK then the home key to get back to the main screen.